



2012-2016 Hino 268 Installation Guide

This guide will show the proper way to install a Dual-Vision XC4 Camera in a 2012-2016 Hino 268. Please review the Service Bulletins for grounding and making connections prior to installing. In this guide you will find dash removal, wire locations, & mounting locations.

After testing and verifying power wires, disconnect the negative battery terminal to prevent any accidental shorts or blown fuses

Verify no vehicle service lights are on prior to installation. Contact a Fleet Manager immediately if the vehicle has any damage

UPDATED October 15th, 2018

NEW PART

Harness DV457 is needed if trigger wires are being connected

For Technical Support please contact our support team at:

Techsupport@Roscovision.com



Gray – Caution

Red – Warning

Blue – Extra Installation Parts Needed

Purple – New Installation





2012-2016 Hino 268 Installation Guide

Before starting your install, its best to prep the windshield for recorder mounting
Giving the VHB tape time to cure before mounting the Recorder will give you a permanent bond and prevent recorders from falling.




- A- Squeeze to release primer and apply to the windshield
- B- Apply Primer to the bracket
- C- Wait for the primer to dry leaving a dull haze on the windshield

IMPORTANT: VHB Tape should only be applied when windshield temperature is within 50°F-100°F (10°C-38°C) to allow proper curing of mounting adhesive pads.

Run the defrost on high heat or use a heat gun in colder temperatures

After windshield is the correct temperature apply the VHB tape marked **PERMANENT** by rolling the tape on the windshield (D)




Using your thumb push firmly around all edges of the VHB tape

Proceed to the next page for Step 1 of the installation



2012-2016 Hino 268 Installation Guide

Installation Layout



Before starting your installation please take note of component mounting locations.





2012-2016 Hino 268 Installation Guide

Step 1 - Dash Removal:

Power connections & Mounting location can be accessed on the passenger side of the truck

- Pry the dash starting at the bottom (Photo A)
- This will give you access to mounting location of the PDC & the Modem
- Remove the four 10MM bolts securing the top panel (Photo B) and center console. Pull the top panel off, and pull the side panel enough to reach the power connections.

A



B






2012-2016 Hino 268 Installation Guide

Step 2 - Power Connections:

- Locate the white 15 pin plug located under the support brace (Photo C)
- Connect the RED **Constant wire** to the vehicle **white wire** & the YELLOW **ignition wire** to the vehicles **blue wire**. **These wires will have clear factory butt connectors already attached to them.**
- Make your ground connection on the support brace above the plug. Be sure to follow the "Installation Technique" before making your connections.

C






2012-2016 Hino 268 Installation Guide

Step 3 - Antenna Mounting:

The Manufacture recommends mounting the antenna on the windshield

Mount the antenna on the same side of the vehicle as the PDC



Notice the angled part of the antenna is on the **inside** of the vehicle (Photo A & B). Make sure the **FLAT SIDE** of the antenna has a **CLEAR VIEW OF THE SKY** and is facing **OUTSIDE** (Photo C)



After all connections are made, coil up all the extra antenna cable (Photo A)

Never bend the cable. This will cause signal loss and damage to the antenna (Photo B)

Please refer to the Antenna Installation Guideline for complete details





2012-2016 Hino 268 Installation Guide

Step 4 - PDC & Modem Connections:

- Connect the USB cable from the modem to the PDC and secure with a zip tie (Photo A)
- Connect the Antenna cable to the modem (Photo B)
- Make these connections prior to mounting the modem & PDC
- Make sure the screw on the modem cover is secured and doesn't move or bend (Photo C)



Connect the MIMO 1 antenna wire to the Modems PRI connector



Connect the MIMO 2 antenna wire to the Modems DIV connector




2012-2016 Hino 268 Installation Guide

Step 5 – PDC & Modem Mounting Location:

- The PDC & the Modem are located under the dash panel on the passenger side of the vehicle, on top of the fuse panel.
- Using self-tapping screws, mount the PDC & the Modem to the support bracket

DO NOT SCREW INTO THE VEHICLES PLASTIC VENT





**PLEASE READ THE RECORDER MOUNTING & VHB TAPE INSTALLATION GUIDELINE BEFORE
PROCEEDING TO THE NEXT STEP**





2012-2016 Hino 268 Installation Guide

Step 6 - Camera Mounting and wire Routing:



For small passenger vehicles, mount the Recorder under the rear-view mirror (Photo A).

If the vehicle has any factory sensors under the rear-view mirror, mount the Recorder to the right of the mirror, not causing a distraction to the driver (Photo B).

For larger trucks or busses (With split windows), mount the Recorder on the right panel (Photo C) and INSIDE the wiper swipe. Keeping the Recorder INSIDE the swipe will ensure rain or snow will not interfere with the video.

When working on emergency vehicles use extreme caution when routing wires around emergency lights and equipment (Photo D)

Always pull down the vehicles sun visors to make sure they don't block or interfere with the Recorder or the video (Photo E). Notice the swipe of the wiper blades. For vehicles like this, mount the Recorder under the visor, inside the swipe.





2012-2016 Hino 268 Installation Guide

To verify proper angle & correct mounting, press the driver activity button. Logon to your Rosco account and view activity to confirm proper angle

The screenshot shows a web browser window displaying the Rosco fleet management interface. The main content is a live video feed from a truck's perspective, showing a green truck at an intersection. The video feed includes a timestamp '2018/05/10 08:17:00', channel information 'CH1 Q1 4FPS ROSCO', and an RSSI signal strength of '-13'. Below the video are four numbered buttons (1, 2, 3, 4) and a search bar with 'Search' and 'Clear Search' buttons. To the right of the video is a table with two columns: 'Status' and 'Live Video'. Below the table is a checkbox for 'Limit Allowed Assets' and a text input field for 'Allowed Assets' with the value '12'.

Status	Live Video
Offline	Launch
Offline	Launch
Online	Launch
Online	Launch
Online	Launch
Online	Launch
Online	Launch
Online	Launch
Offline	Launch
Offline	Launch
Online	Launch

